

Bluetooth Adapter Installation

1. Insert the driver software CD into your computer's optical drive.
2. Follow the on-screen instructions.
3. When the "Bluetooth Device Not Found" or "No Bluetooth device was detected" window appears. Insert the USB Bluetooth adapter in the USB port.

Note: Do not connect the Adapter to your computer until the software drivers are installed.

4. Follow the on-screen instructions then click Finish to complete the installation.

If your computer does not have an optical drive, you can download the latest driver from WWW.targus.com

Basic Operations

To start Bluetooth in the Windows system tray, right-click the Bluetooth icon and select Start the Bluetooth Device / Turn Adapter On. The Bluetooth icon is blue in color with a white insert when the Bluetooth software is running.

To stop Bluetooth in the Windows system tray, right-click the Bluetooth icon and select Stop the Bluetooth Device / Turn Adapter Off. The Bluetooth icon is blue in color with a red insert when Bluetooth is stopped.

Verifying the Adapter is installed

After installing the adapter software (for Vista / 7 / 8):

1. Click Start/Control Panel/Hardware/Device Manager.
2. Check under 'Bluetooth Radios' that a 'Broadcom BCM 20702 Bluetooth 4.0 USB device' is installed.

Configuring Bluetooth Devices

The Bluetooth tray resides in the Windows system tray, which is normally located in the lower-right corner of the screen. The Bluetooth tray provides fast access to most Bluetooth Operations.

From the Bluetooth tray you can (Windows 8/7 / Vista):

- Add a Bluetooth device: right-click the Bluetooth icon and then select Add a Device.
- Show a Bluetooth device: right-click the Bluetooth icon and then select Show Bluetooth Device.
- Access the Bluetooth Configuration Panel: right-click the Bluetooth icon, and then select Open Settings.